

Type of Construction	Material	Test	Frequency of Acceptance Samples and Tests for Job Control	Construction Stages for Obtaining Sample or Test	Sample Size	Procedures		Remarks	
						Sampling Method	Test Methods		
Chain Link Industrial Fence	Chain Link Fence	Chemical and Physical	Certified Tests or sampled at project level. One sample per project	Before delivery to work site See ALDOT-195	3 ft (1 m) by width of roll		Visual for damages and rust	Submit with BMT-1	
	Barbed Wire								
	Metal Line Post	Chemical and Physical	Certified Tests or sampled at project level	Before delivery to work site  See ALDOT-195	1 each		Visual for damages	Submit with BMT-1	
	Metal Corner Post								Same as Line Post
	Metal Brace Post								Same as Line Post
	Caps Miscellaneous Hardware and Fittings	Chemical and Physical	Certified Tests or sampled at project level	Before incorporation in work  See ALDOT-195	1 each		Visual for damages and rust	Submit with BMT-1	
	Gates and Fittings								
	Protective Cage Tubing								
	Concrete for Setting Posts		Small amounts may be obtained from any source approved by Division Materials Engineer without Job Control Tests. Amounts greater than 175 yds <sup>3</sup> (135 m <sup>3</sup> ) on any project see Section 501 Minor Structure Frequency						

Type of Construction	Material	Test	Frequency of Acceptance Samples and Tests for Job Control	Construction Stages for Obtaining Sample or Test	Sample Size	Procedures		Remarks
						Sampling Method	Test Methods	
	Tension and Tie Wire	Chemical and Physical	Certified Tests. See ALDOT-195; Section 2.3, or sampled at project level	Before installation	Tension- 1- 3 ft. (1 m) tie, 3 each			Submit with BMT-1