

Type of Construction	Material	Test	Frequency of Acceptance Samples and Tests for Job Control	Construction Stages for Obtaining Sample or Test	Sample Size	Procedures		Remarks
						Sampling Method	Test Methods	
Abutment and Bulkhead Anchors	Prefabricated Metal or Precast Pretressed Concrete Bulkheads	Chemical and Physical	Precast ALDOT-195; Section 2.2.1 Metal ALDOT-195; Section 2.3	Before incorporation in work			Visual for damage	
	Wire Rope	Chemical and Physical	ALDOT-195; Section 2.3 or ALDOT-195; Section 2.1.3	Before incorporation in work	9 ft (3 m)	ALDOT-210	Visual for damage	Use Sample Information Card Form BMT-1
	Anchor Assemblies Including Miscellaneous Metals	Chemical and Physical	ALDOT-195; Section 2.3 or ALDOT-195; Section 2.1.3	Before incorporation in work	1-each item	ALDOT-210	Visual for damage	Use Sample Information Card Form BMT-1