

Repair or Raising Existing Bridges

Type of Construction	Material	Test	Frequency of Acceptance Samples and Tests for Job Control	Construction Stages for Obtaining Sample or Test	Sample Size	Procedures		Remarks
						Sampling Method	Test Methods	
Repair or Raising Existing Bridges	All New Components	See Section 510 for applicable instructions						